


LASER COMPETITION I



1. Unpack tent and lay out flysheet and inner.
(Note: The inner tent is already attached to the inside of the flysheet)
2. Carefully assemble the alloy pole. Ensure all the joints are fully connected.
3. Slide pole through flysheet pole sleeve, shown as the dotted line on the diagram above.
4. Insert each pole-end into the corresponding eyelet tab on the hem of the flysheet, tabs are located at points A and B on diagram above.
5. Peg out: in the following order:
 - i) tape attached to each end of the inner
 - ii) guy rope at each end of the flysheet
(note: the carbon fibre poles should slope out slightly at the top)
 - iii) remaining inner and flysheet tapes and elastics

Note: A pole sleeve cover is provided with Laser Competition. Attach by tying to the webbing loop at the pole base and loops sewn into the pole sleeve.

The Laser Competition I is supplied with:
1 alloy pole, 2 black carbon fibre poles
10 alloy pegs

To validate your warranty register online at www.terra-nova.co.uk

Pour valider votre garantie, enregistrez-vous en ligne sur www.terra-nova.co.uk

Zur Bestätigung Ihrer Garantie registrieren Sie bitte online unter www.terra-nova.co.uk

For tent pitching and care instructions visit www.terra-nova.co.uk

Pour consulter les instructions de montage et d'entretien des tentes, visitez www.terra-nova.co.uk

Anweisungen zur Zeltaufstellung und Pflege finden Sie unter www.terra-nova.co.uk