


## LASER COMPETITION 2 PITCHING INSTRUCTIONS



1. Unpack tent and lay out flysheet and inner.  
(Note: The inner tent is already attached to the inside of the flysheet)
2. Carefully assemble the alloy poles  
Ensure all the joints are fully connected
3. Slide long pole through flysheet pole sleeve as marked on diagram above. Insert pole ends in corresponding eyelets at points A and B.
4. Insert short poles at C and D, between the pocket under the hood and hem eyelet.
5. Peg out in the following order:
  - i) Guy cord at each end
  - ii) Remaining inner and flysheet elastics/guys

Note: A Pole sleeve cover is provided with Laser Competition. Attach by tying to the webbing loop at the pole base and loops sewn into the pole sleeve.

The Laser Competition 2 is supplied with:

- 1 long alloy pole, 2 short alloy pole
- 10 alloy pegs

**To validate your warranty register online at [www.terra-nova.co.uk](http://www.terra-nova.co.uk)**

Pour valider votre garantie, enregistrez-vous en ligne sur [www.terra-nova.co.uk](http://www.terra-nova.co.uk)

Zur Bestätigung Ihrer Garantie registrieren Sie sie bitte online unter [www.terra-nova.co.uk](http://www.terra-nova.co.uk)

**For tent pitching and care instructions visit [www.terra-nova.co.uk](http://www.terra-nova.co.uk)**

Pour consulter les instructions de montage et d'entretien des tentes, visitez [www.terra-nova.co.uk](http://www.terra-nova.co.uk)

Anweisungen zur Zeltaufstellung und Pflege finden Sie unter [www.terra-nova.co.uk](http://www.terra-nova.co.uk)