


# QUASAR / ULTRA QUASAR QUASAR ETC /



1. Lay out the inner tent.
2. Carefully assemble the 4 poles. Ensure all the joints are fully connected.
3. Slide the blue poles through the blue marked pole sleeves.
4. Slide the red poles through the red marked pole sleeves.
5. Matching the colour of the eyelet tape on the inner with the pole, insert a pole end in to the outer most eyelet.
6. Peg out inner tent.
7. (For Quasar ETC) only - slide the extra red pole through the flysheet pole sleeve.
8. Throw flysheet over inner tent.
9. Matching the colour of the eyelet tape on the hem of the flysheet with the pole, insert a pole- end in to the outer most eyelet on each tape.
10. Peg out flysheet.
11. Remember to adjust the flysheet tension as conditions alter. (The flysheet will tighten in strong sunlight and slacken if it gets wet).

Supplied with:

Quasar / Ultra Quasar:

4 Alloy poles

22 Titanium pegs (Ultra Quasar),

22 Alloy pegs (Quasar)

Quasar ETC:

5 alloy poles

26 alloy pegs

**To validate your warranty register online at [www.terra-nova.co.uk](http://www.terra-nova.co.uk)**

Pour valider votre garantie, enregistrez-vous en ligne sur [www.terra-nova.co.uk](http://www.terra-nova.co.uk)

Zur Bestätigung Ihrer Garantie registrieren Sie sie bitte online unter [www.terra-nova.co.uk](http://www.terra-nova.co.uk)

**For tent pitching and care instructions visit [www.terra-nova.co.uk](http://www.terra-nova.co.uk)**

Pour consulter les instructions de montage et d'entretien des tentes, visitez [www.terra-nova.co.uk](http://www.terra-nova.co.uk)

Anweisungen zur Zeltaufstellung und Pflege finden Sie unter [www.terra-nova.co.uk](http://www.terra-nova.co.uk)