POLAR STORM 3 ETC



1. Unpack and lay out the flysheet, with the black pole sleeves uppermost.
(Note the inner tent is already attached.)

2. Unpack the 4 poles. Carefully join each pole section together. Pass the dome end of each pole through the semi-sircular cutout in the snow skirt at points a, b, c, d.
Then slide through the 4 black pole sleeves.

3. Insert the other ends of each pole in the eyelets provided. (a-b, c, and d)

4. Peg out the flysheet hem at each end, using the webbing loops provided

5. Peg out the back of the inner tent.

6. Peg out the guy ropes provided.

Note: Polar Storm tents are factory fitted with a black snow shirt/valance attached to the hem of the flysheet, for severe winter conditions.
This can be partially or completely lifted using the toggles provided, for maximum ventilation/safety.

- Never cook or use other combustion appliances in your tent or porch.
- Make sure ventilation openings are open all the time to avoid suffocation, and read the fire and ventilation precaution labels carefully.

The Polar Storm 3 ETC is provided with:

4 alloy poles
8 snowstakes and 16 'v' alloy angle pegs

To validate your warranty register online at www.terra-nova.co.uk
Pour valider votre garantie, enregistrez-vous en ligne sur www.terra-nova.co.uk
Zur Bestätigung Ihrer Garantie registrieren Sie sie bitte online unter www.terra-nova.co.uk
For tent pitching and care instructions visit www.terra-nova.co.uk
Pour consulter les instructions de montage et d'entretien des tentes, visitez www.terra-nova.co.uk
Anweisungen zur Zeltaufstellung und Pflege finden Sie unter www.terra-nova.co.uk